







Gebruikte materialen	Onderhoudsproducten	Onderhoudsmethoden
 Niet-schurende spons of zachte doek  Trekker	Niet-schurende huishoudproducten voor dagelijks gebruik. Gebruik geen agressieve stoffen of chloorhoudende onderhoudsproducten. Het gebruik van oplosmiddelen wordt afgeraden.	Dagelijks onderhoud met een trekker. Douchezone: maandelijkse reiniging met een niet-schurende spons of een vochtige doek en een sterk verdund neutraal reinigingsmiddel. Gebied buiten de douche: periodieke reiniging met een niet-schurende spons of een vochtige doek en een sterk verdund neutraal reinigingsmiddel.

☞ In geval van vuilophoping op de voegen kan dit worden verwijderd met een niet-schurende spons, net als bij regulier onderhoud.



Equipment used	Cleaning products	Cleaning methods
 Non abrasive sponge, damp cloth  Squeegee	Ordinary household cleaning products, non abrasive. Do not use aggressive substances or chlorine-based cleaning products. Solvent-based cleaners are not recommended.	Daily cleaning with squeegee Shower area: monthly cleaning with a non-abrasive sponge or damp cloth and a very diluted neutral detergent Outside shower area: clean periodically with a non-abrasive sponge or damp cloth and very diluted neutral detergent.

☞ In case of dirt buildup on the joints, it can be removed with the use of a non-abrasive sponge, just like for regular maintenance.

