








Damp maintenance equipment
Sponge without abrasive



Manual washing equipment
Microfibre disposable mop or gauze

	Equipment used	Cleaning products	Cleaning methods
First use	 	Alkaline detergent	<ul style="list-style-type: none"> • Manual cleaning with an alkaline detergent + sponge without abrasive • Recovery of water with a microfibre disposable mop • Rinsing with clear water
Daily care Once a day		Neutral detergent or disinfectant detergent	<ul style="list-style-type: none"> • Manual cleaning with a sponge without abrasive + neutral detergent for the surfaces located in areas 1 or 2 and a disinfectant detergent for the surfaces located in areas 3 and 4 and eventually in area 2 or • Steam cleaning
Periodical cleaning Once a month and at patient's departure in areas 1 and 2 Once a week and at patient's departure in areas 3 and 4		Disinfectant detergent	<ul style="list-style-type: none"> • Manual cleaning with a disinfectant detergent (without amine) and a sponge without abrasive or • Steam cleaning (if manual daily maintenance)
Deep cleaning Once a month		Alkaline detergent	<ul style="list-style-type: none"> • Manual cleaning with an alkaline detergent + a sponge without abrasive • Rinsing with clear water