

Mipolam Wall Panel Maintenance

Wall panels have been tested for their resistance to most of the cleaners, disinfectants and antiseptic products used by clean industry and healthcare establishments.

Amongst others, the products listed below have been tested and proved to efficient without causing any damages to the Mipolam Wall Panels:

DETERGENTS	SURFANIOS DETERGANIOS
DETERGENT DISINFECTANTS	DS5001 DIVOSAN S4
DESCALERS	TASKI CALCACID
PAINT STRIPPERS	TASKI radical SUMA D9.7
DEGREASER DISINFECTANTS	DDM
OTHERS	70% surgical alcohol Betadine Ammonia

For better results when cleaning the Mipolam Wall Panels, we recommend the following products:

- Ammonia
- Ethanol
- Isopropyl alcohol
- Heptane

IT IS IMPORTANT TO USE SOLVENTS THAT LEAVE NO RESIDUE, EITHER GREASY OR DRY.

In all cases, test the product first on a left-over piece of panel. Reactions will vary depending on the color of the panels and the solvents used and the concentration.



SOLVENTS NOT TO BE USED

- Mineral spirit
- Paint thinners

For any information, please refer to Gerflor Technical Services.

Gerflor USA, Inc.
750 Veterans Parkway
Bolingbrook, IL 60440
Tel: 877-Gerflor (877-3567)
gerflorusa.com