



INSTALLATION INSTRUCTIONS

GERFLOR TECHNIC EL5 TILES

These instructions are specifically written for the installation of the following products:

Product	Size	Installation direction	Seams Welded
Mipolam Technic EL 5 in tiles	Approx. 24" x 24"	90°	CR 40
Welding Rod	4mm		CR 40

Important Note: Before installing, refer to Gerflor Installation Handbook for acclimation, job site conditions, subfloor prep, and other general installation recommendations.

1. GENERAL INFORMATION

- 1.1. Gerflor ESD flooring products are formulated to withstand high moisture conditions. To perform as designed, the concrete should be properly prepared to create a contaminant free and porous substrate.
- 1.2. Gerflor ESD flooring products are not designed to withstand hydrostatic or osmotic pressure.
- 1.3. *The guidelines offered within this document are not intended to be all inclusive. Only qualified, professional flooring technicians experienced in the field of resilient flooring should proceed with this installation system.*
- 1.4. It is recommended to mechanically prepare the concrete via grinding or bead blasting the surface to achieve a CSP 1+, clean and porous substrate.
- 1.5. Moisture and pH testing must be performed in accordance with ASTM F710-22.
- 1.6. Adhesive bond tests are recommended to ensure adequate bonding to the substrate.
- 1.7. Do not install material that has visible defects or damage. A contractor that installs material that has visible defects or damage assumes responsibility for the damaged material.

2. INSTALLATION OF TECHNIC EL5 ESD TILES

Note: Seams of conductive and static dissipative tiles must always be heat-welded.


3. COPPER STRIP LAYOUT FOR TECHNIC EL5 TILES USING GERFIX TPS+ ADHESIVE

NOTE: THE INSTALLATION OF THE COPPER STRIP IS RELATED TO THE TYPE OF ADHESIVE USED FOR THE PROJECT. SEE RECOMMENDED ADHESIVE INSTRUCTIONS BELOW FOR MORE DETAILS.

- 3.1. Copper strip comes in rolls of 656 linear feet.
- 3.2. The copper strip is 3/8" wide and 0.003" thick.
- 3.3. Layout copper strip and coordinate grounding with a certified electrician.
- 3.4. **For rooms less than 400 sq. ft. use one copper strip 6'6" long. Allow extra copper at the wall for proper grounding.**

NOTE: THE TILES MUST BE GROUNDED EVERY 400 SQ. FT. AND HAVE A MINIMUM 6'6" LONG

COPPER STRIP BENEATH.




- 3.5. Layout copper strip and coordinate grounding with a certified electrician.
- 3.6. For rooms ≤ 400 sq. ft., a piece of copper strip 6'6" long under the tiles and coming out along the wall to be grounded by a certified electrician.
- 3.7. For rooms > 400 sq. ft., install a copper strip on the perimeter and a piece of 6'6" long for every 400 sq. ft.
- 3.8. The copper strips must be grounded by a certified electrician.
- 3.9. Install copper strip with the conductive adhesive.

NOTE: Install copper strip with the conductive adhesive before starting the installation of the flooring. Spread conductive adhesive in narrow strips to the substrate according to copper strip layout and lay copper into wet adhesive. Immediately flat trowel, applying pressure to carefully smooth the copper and remove any excessive adhesive. Allow adhesive to dry before laying out tiles. When installing the tiles, spread adhesive on the entire surface being careful not to damage the copper.

4. TILE LAYOUT

- 4.1. Chalk the centre lines of the work area in both directions so that one line is parallel to the length of the room and that the second line is on a 90° angle to the first line.
- 4.2. Position centre lines to allow the perimeter tiles to be \geq to $\frac{1}{2}$ tile.
- 4.3. Before spreading adhesives, it is recommended to lay one or two rows of tiles along both centre lines to check for proper alignment.
- 4.4. Mix tiles from different boxes to obtain a consistent layout.




INSTALLATION INSTRUCTIONS

GERFLOR TECHNIC EL5 TILES

- 4.5. Be certain this tile is installed on the lines to fit the 90° angle.
- 4.6. After the first tile is in place, begin laying tiles outward along both guidelines.
- 4.7. Press tiles firmly against adjoining tiles and press into the adhesive.
- 4.8. Begin stair-stepping the tiles into the field area.
- 4.9. It is recommended to install the tiles in a checkerboard pattern.

5. INSTALLING ESD TILES USING GERFIX TPS+ ACRYLIC ADHESIVE

- 5.1. Always refer to the **Gerfix TPS+ Adhesive Technical data Sheet**
- 5.2. Recommended trowel size is 1/32" x 1/16" x 1/32", covering from 170 to 220 sq. ft. per US gallon. 
- 5.3. To ensure uniform adhesion of the entire surface, apply a workable amount of adhesive at one time.
- 5.4. Maintain a uniform spread rate. Replace trowel (or trowel blade) with every pail used.
- 5.5. Immediately after troweling the adhesive onto the concrete use a medium napped paint roller saturated with adhesive to flatten out visible trowel marks and even out the adhesive. **A double arm roller frame is recommended to ensure an even coat of adhesive.**
- 5.6. "Open time" of the adhesive is dependent upon porosity of the substrate, temperature, and humidity. It is important that the installers familiarize themselves with the adhesive before starting the installations.

<i>Application Characteristics over Porous Substrates (Non-Porous-see note below)</i>		
	<i>Open Time*</i>	<i>Working Time**</i>
Gerflor ESD Floorings	20 to 40 minutes (to reach a tacky state***)	Up to 1.5 hours

* **Open Time:** is the wait time required before installing flooring inot the adhesive.

** **Working time:** is the wait time required before installing flooring inot the adhesive. Exceeding the working time will result in poor adhesion and could lead to peaking of tiles, or gaps.

*** **Tacky:** When adhesive starts to becomes translucent and there is light transfer to the fingers when slightly touched resulting in transfer to the backing of the flooring.

Note: For Non-Porous substrates such as existing flooring or metal, let the adhesive dry completely, with NO transfer to the fingers when touched, then immediately install the flooring and roll with a 100lb. roller.

- 5.7. Install copper strip into the tacky adhesive *just before installing the flooring into the adhesive. Make sure there is no adhesive on top of the copper strip.*
- 5.8. Starting from the center line and working outward, apply the adhesive and install tiles when the adhesive is ready.
- 5.9. Press tiles firmly against adjoining tiles and press into the adhesive.
- 5.10. Periodically, lift the edge of a tile to confirm transfer of adhesive to the back of the flooring. There must be adhesive transfer for the tiles to be adequately secured to the substrate.
- 5.11. Once flooring is placed into the adhesive, immediately roll thoroughly with a 3 section 100-lbs roller in both directions.



INSTALLATION INSTRUCTIONS

GERFLOR TECHNIC EL5 TILES

- 5.12. Always roll seams, at the walls, and under toe kicks with a hand roller to ensure 100% transfer of adhesive.
- 5.13. During the installation, with the lights on and off, always double check the flooring for bubbles with portable, ambient, and/or fixed lighting.
- 5.14. Heat welding can proceed 24 hours after installation
- 5.15. **Avoid adhesive displacement by prohibiting traffic for a period of 24 hours and 72 hours for rolling loads.**

6. HEAT WELDING - REFER TO THE "HEAT WELDING GERFLOR VINYL PRODUCTS" DOCUMENT

7. ONCE THE INSTALLATION IS COMPLETED

- 7.1. Perform a visual inspection of the project.
- 7.2. Verify every welded seam.
- 7.3. Repair every imperfection before leaving the project.
- 7.4. Make sure that every vertical obstacle such as doorframes is well trimmed and sealed with an acrylic, silicone, or equivalent sealant product.
- 7.5. To maximize the aesthetic appearance and serviceability of the newly installed flooring, provide your customer with a copy of the **Gerflor Maintenance Guide**.